


Functional Testing of Micro-Optics for Automotive™




Simone Francavilla
Project Leader and Product Manager

Alfamation - 33 years of expertise





- Strong R&D and Engineering
- Expertise in Optics
- Deep knowledge in Image Processing
- Experience in Optoelectronics and Photonics











flexmedia XM


MULTIPLE INSTRUMENTS, ONE FAMILY

- Specialty Test Modules
- Audio-Video Generators/Analyzers
- Camera Simulators
- Ethernet-powered, OS-Agnostic

Hyperion[™] Common Test Platform








BATTERY MANAGEMENT PCBA TEST


PixelshooterTM Automated Display Tester






Modularity











Fully Configured Setup!

- Well-established common platform to concentrate efforts on application challenges
- Common-base of components and spare-parts
- Reduced maintenance and semi-automatic calibrations
- One platform, multiple applications

Flexibility






- Multiple Degrees of freedom allowing to test different product variants without retooling and recalibrations
- A powerful and user-friendly software interface to adjust test parameters (SupernovaTM: Alfamation proprietary test sequencer based on NI Teststand)




High Throughput



 Algorithms, Image Processing and results logging are all run in parallel to movements and positioning to remove or reduce the overhead

Parallel Threads



Reliability


• According to the Automotive Industry Action Group (AIAG) if your measurement system's variation is less than 10% of process's variation, then it is acceptable.

	Percentage of Process Variation (%R&R)	Acceptability	
→ (Less than 10%	The measurement system is acceptable	トノ
	Between 10% and 30 %	The measurement system is acceptable depending on the application, the cost of the measurement device, cost of repair, or other factors.	
	Greater than 30%	The measurement system is not acceptable and should be improved	





Production and Clean Room Compatibility



Operator-Friendly User Interface

- Network Integration
- MES Interface

Plant Interface

- Automatic Serial Number reading and Alignment procedure
- Robotized Automatic Wafer loading compatibility


Reduced Operator Workload

Ventilation and Filters Unit for Clean Room integration

Clean Room Compatibility




MLA Decorative Lighting Welcome Carpet and "Driving Intensions"






MLA (Micro Lens Array)




Tested at Wafer-Level!




Projection Module



MLA Decorative Lighting Setup – Projection on Target Plane (i.e. Street)





Test Metrics: Relative Brightness, Contrast\Gradient, Cross Talk\Ghost,


Chromatic Aberration


Speed: Up to 2800 UPH (Units per hour)

Stability: Gage R&R < 10%


Performance


MLA Decorative Lighting Setup – Projection on Arbitrary Surface (i.e. Dashboard)





Testing Setup






Collaborations

Testing Micro-Optics and Assembled Modules

- This is just a portion of Alfamation portfolio and capabilities!
- Alfamation is looking for:
- instruments and test methods to integrate in out test platforms
- new micro-optics and photonics test challenges
- Alfamation, by leveraging its strong engineering capabilities can:
- supply innovative automated test solutions
- develop **new test methods**

- not only at wafer level!







CONTACTS



For more info please write to: OptoTeam@alfamationglobal.com



Subscribe for Company News: linkedin.com/company/alfamation

EUROPE HEADQUARTERS

ALFAMATION SPA
Via Cadore, 21
20851 Lissone (MB) – Italy
Phone: +39-039-243-51
info@alfamationglobal.com

ASIA PACIFIC OFFICE SUZHOU ALFA TEST EQUIPMENT CO., LTD.

Floor 1, Building A, Distr.7
ZhongkeNaMi Science Park, No.128,
FangZhou Road, Jiangsu Province,
Suzhou City, 215000, China
Phone:+86 188 6232 1911

Conoscopy Mode: DOEs and MOEs testing





Module Collimation Infrared VCSEL Array Lens DOE Module Infrared VCSEL Array MOE

Tested at Wafer-Level!

DOEs and MOEs are used for both Dot Pattern Projection (red) and Flood Illumination (orange) in the face id and gesture recognition procedure.


Conoscopy Mode: Test Principle and Configuration

- High-resolution camera + Conoscope
- High acceptance angle

105°

Different conoscopes design for different needs!

Angular Map



Test Metrics: Angular Distribution, Transmission Efficiency, Diffraction Efficiency, Uniformity Speed: Up to 3000 UPH (Units per hour) Stability: Gage R&R < 10%

Performance




Collimated Beam Profiling Mode: Collimation Lenses testing







Collimation Lenses are components used in a very wide range of applications. In consumer electronics, they are often paired with DOEs for **face ID** and **gesture recognition**.



Collimated Beam Profiling Mode: Test Principle and Configuration

- Distance sensor for wafer warpage
- Focus scan for best focus and FFL measurement
- Steering mirror, camera sensor and integrating sphere





Test Metrics: Spot Size, Transmitted Power, Flange Focal Length, Effective Focal Length

Speed: Up to 1500 UPH (Units per hour)
Stability: Gage R&R < 10%

Performance





Coupling Micro-Optics Mode: Telecom and Imaging optics testing

Coupling optics are often used in telecommunication industry and for imaging purposes.



Coupling Micro-Optics Mode: Test Principle and Configuration

