

Advancing Consumer Optics with Ultra-Precision Machining and Replication

Micro-Optics Summit Amsterdam 03.12.2024

Jonas Wielandts – Managing Partner & CBO jonas.wielandts@upmt.be

Company



Incorporated in 2013. 100% Family owned.



Continuous technology developments in diamond machining and polymer replication





Optics manufacturing by diamond machining and/or replication processes



> 100 customers worldwide



Located in Liège (Belgium)




Our services

Technological solutions for manufacturing of your high precision optical and mechanical parts


DPI® Lens array masters / inserts

Plastic optics

SPDT Services







Proprietary and Confidential!



DPI® on-axis SPDT machining

Dynamic Part Indexing (DPI®) is:

- A patented device 100% developed and owned by Wielandts UPMT
- Sequentially 2/3-axis turning of each lens of an array on the workspindle axis for best form and roughness
- Dynamically offset the part wrt the work-spindle in a balanced manner using eccentric rotary movements
- All lenses machined on same on-axis position
 → repeatable form and roughness
- Design freedom: all lenses can be different (freeform) to compensate for replication repeatable errors







DPI® masters markets and applications

- MLA sensors for mobile applications, LiDAR,
 ...
- Automotive MLA headlights/carpets
- Masters for roll-to-roll replication for lighting applications
- Single lenses fully populated masters for camera applications
- WLO master for healthcare applications
- WLO master for LBS optics
- ...









Plastic optics manufacturing processes

1 Injection molding for lens arrays

2 HiFi Optics® compression molding

3 Diamond turning





Injection molding for lens arrays


Using:


- Proprietary molding tool
- DPI® manufactured mold inserts


Applications: AR/VR, LiDAR, lighting, healthcare, ...

Special	injection	molding	proces
Special	mection	molalia	DIOCESS

SFE	Down to 300 nm p-v	
Ra roughness	< 10 nm	
Thickness	0.6 - 3 mm	
Max slope	< 40°	
Fill factor	100%	
Double sided	Yes	
Alignment	<10µm	
Shapes	Aspheres, diffractives, freeforms	
Materials	Optical thermoplastic materials: PMMA, PC , COC, COP	









HiFi Optics® compression molding for AR


Proprietary Isothermal Compression Molding Process



1. Preforms inserted in multi-cavity ultra precision mold with adapted alignment system



2. Isothermal compression molding of lenses



3. Isotropic shrinkage of lenses during cooling



No temperature gradient for high shape accuracy and low residual stress




4. Demolding of HiFi Optics® lenses



HiFi Optics® compression molding for AR

Proprietary Isothermal Compression Molding Process



	HiFi Optics® compression molding	
Form irregularity	Down to 150 nm p-v	
Ra roughness	< 5 nm	
Position accuracy	Optical surfaces co-alignement: 1-2 µm	
Minimum thickness	< 200 μm	
Aspect ratio	> 5	
Max slope	Up to 75°	
Birefringence	Down to 10nm/cm	
Shapes	Aspheres, diffractives, freeforms	
Materials	PMMA, PC (Mitsubishi EP Series,), COC (Mitsui APEL), COP (Zeonex)	







UPMT customer projects for AR/VR





HiFi Optics® compression molding use case: pancake lenses















HiFi Optics® compression molding use case: geometric waveguides











Plastic optics manufacturing services

From mold engineering to optics manufacturing and test, including:

- Mold and/or tooling design and engineering
- CNC machining of mold and/or tooling (3- and 5-axis)
- Diamond machining:
 - DPI®
 - Conventional 2-axes diamond turning
 - Freeform 3-axis turning
- Optics replication:
 - Special injection molding
 - HiFi Optics® compression molding
- Direct diamond machining
- Optical coatings from recognized suppliers
- Final shape : dicing post processing (diamond saw dicing, milling)
- Metrology:
 - SFE
 - Birefringence
 - Roughness
 - Centration

